

For Removal of Deep Scratches and Stone Chips. This kit can be used to remove deep scratches or stone chips where the primer or metal work is exposed (see diagram below).

LACQUER	
BASE COAT	
PRIMER	
STEEL	

### **This Kit Contains:**

- 30ml Custom Colour Base Coat Paint
- 30ml Clear Lacquer
- 30ml Scratch Cleaner
- 30ml G3 Advanced Liquid Compound
- 5x Application Spears
- Microfibre Polishing Cloth
- 2x Mini Sheets of Wet 'n' Dry (P2000)
- Neoprene Rubbing Block

# Step 1

Remove any flaking paint or dirt from the damaged area and thoroughly clean the area with scratch cleaner from the kit using an application spear.

# Step 2

Shake the base coat paint bottle and, using the application spear, apply 1 – 2 layers of base coat paint, leaving around 30 minutes between layers. Please ensure you leave enough depth for the lacquer.

Please leave 1-2 hours for the base coat to harden.

# Step 3

When the base coat has dried, apply 2 – 6 layers of lacquer using the application spear, leaving around 30 minutes between layers and finishing with the lacquer in a slight bump above the surface of the existing paintwork. Please ensure that the lacquer is raised ABOVE the level of the existing paintwork as this reduces the

#### possibility of over using the flatting paper later. **Please leave at least 24 hours for the lacquer to harden.**

## Step 4

When completely dried, carefully fold a piece of wet 'n' dry around the neoprene rubbing block, dip in a pot of water, and LIGHTLY rub along the scratch (not in circular motion) to ensure a smooth, flat surface. Ensure you keep the paper wet throughout the flatting process. If the new lacquer isn't level with the existing paint work then dips may be visible after flatting. If this happens clean the area thoroughly and reapply lacquer and allow 24hrs to dry. Don't be tempted to keep flatting to try and get rid of the dips, this can over thin the existing lacquer.

Apply a small amount of G3 Advanced Liquid Compound to the damp microfibre Polishing Cloth and rub over the area in circular motion until the gloss returns and wet 'n' dry paper marks have disappeared. Remove any residue with a soft, dry cloth and buff.

PLEASE NOTE: The results from using the Scratch Master Kit will depend entirely on the care taken by the user, please apply slowly and carefully taking as much time as needed.